


# 469149 Rev02

**Please read these instructions thoroughly before installation.**



**60kg  
132lb**

If you have any questions or need  
spare parts don't worry, we're happy to help.

**Customer Helpline**

**0333 320 0463**

**Helpline Open** Mon to Thurs 9am - 5pm, Fri 9am - 4pm


**Online Support**

**[www.avfgroup.com/support](http://www.avfgroup.com/support)**


**AVF Group Ltd.** Hortonwood 30, Telford, Shropshire, TF1 7YE, England

## Assembly Overview


### Fit the TV Mounting Plate



### Fit the Wall Bracket




### Hang the TV




## Tools Recommended








Stud Finder




Ø10mm (25/64")  
Masonry



Ø3mm (1/8")  
Wood



## Suitable Wall Types



Solid Wall



Wood Stud

## Index

**1** Measure the TV fixing holes Width and Height

**2** Preparing the TV Mounting Plate

**3** Fitting the TV Mounting Plate

**4** Fitting the Wall Bracket

**5** Fitting the Wall Bracket Covers

**6** Hanging the TV

**7** Fitting the Cable Management

**8** Tilt Adjustment

**9** TV Levelling

Retain all packaging in case the product needs to be returned.

Contents may vary from photography / illustrations.


You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.

This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.



It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).

AVF accept no responsibility for any damage or loss caused by installing this product in a substandard wall.


## Boxed Parts




## TV Screws, Reducers and Spacers



# 1 Measure the TV fixing holes Width and Height



If width (X) is greater than 400mm or height (Y) greater than 400mm STOP installation now and contact the customer help line.



**M4 = K1-K2**

**M6 = K3-K4**

**M8 = K5-K7**

You are provided with 3 diameters of TV fixing screws **M4**, **M6** and **M8**. Determine the screw diameter that fits and remember for step 3

## 2 Preparing the TV Mounting Plate

Use the option that fits your TV.


### OPTION 1

- (X) 75mm x (Y) 75mm
- (X) 100mm x (Y) 100mm
- (X) 100mm x (Y) 200mm
- (X) 200mm x (Y) 100mm
- (X) 200mm x (Y) 200mm

When attaching adaptors **C** you must always use **HOLES x4** and either of the **SLOTS**.


### OPTION 2

- (X) 75mm - 400mm (Y) 75mm - 400mm








Before you fully tighten the TV mounting plate check that the mounting plate holes line up with the fixing holes on the back of your TV.

### OPTION 1




## OPTION 2


Adaptors **C** can be fixed in different positions in the slots on Plate **B** to match your TV fixing holes.



Top



Example shown is 400 x 400 fixings




**H** x8 **I** x8 **J** x16

### 3 Fitting the TV Mounting Plate

#### No Spacers


For TVs with flat / unobstructed back.







#### Spacers

**M1/M2**

For TVs with irregular / obstructed back.




#### WARNING



After completing step 3 you will have fittings left over, please keep for future reference.





Attach the TV Mounting Plate to the back of your TV using suitable screw, reducer and spacer combinations.





## 4 Fitting the Wall Bracket

Solid Wall






Remove Dust from Hole.

Wood Stud




Ensure bracket is in the centre of the wood stud



Lubricate screw thread with soap.



DO NOT overtighten screws.  
Tighten screws by hand only.



Lubricate screw thread with soap.




DO NOT overtighten screws.  
Tighten screws by hand only.

**N** x3

**O** x3


**N** x3

## 5 Fitting the Wall Bracket Covers




## 6 Hanging the TV


Hanging the TV



Locking the TV




**7** Fitting the Cable Management



## 8 Tilt Adjustment

Adjust screws to achieve perfect tilt resistance if required.



## 9 TV Levelling

